



# Northern Lake Service Inc.

## ENVIRONMENTAL ANALYTICAL LABORATORY

### Iron Bacteria - \$38

#### Kit includes:

- 1 x 1 150 mL Sterile Clear Plastic Bottle

#### Sampling Procedure for Iron Bacteria:

##### **READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH SAMPLE COLLECTION**

\*Sampling video available on our website at [www.nslab.com](http://www.nslab.com) under support material

1. Sample a cold water faucet that precedes any treatment in your home. The sample faucet nearest to the pressure tank works well for this sampling method.
2. Run water at maximum flow for at least 2 minutes.
3. Sanitize the sampling faucet (with screen removed) by heating the faucet and surrounding piping with a propane torch for about 30 seconds. A butane lighter may be used as an alternative but should then be heated for about 60 seconds. **DO NOT HEAT A PLASTIC FIXTURE!**
4. Collect the sample by again flushing your water sampling faucet with about 1 gallon of water and then turn your water down to a slow steady stream.
5. Remove the custody wrapper on the top of the bottle.
6. Unscrew the cap of the bottle and **without setting the cap down**, fill past the 100 mL fill line on the bottle, and re-cap immediately. **DO NOT TOUCH THE INSIDE OF BOTTLE OR CAP.**

#### Follow the return shipping instructions to ensure kit is shipped back to the lab properly:

- Fill out the required information below and label your sample bottles with date/time of collection.
- Samples are accepted 8:00 am to 4:00 pm Monday – Thursday at the Waukesha lab, and until noon on Friday. Do not ship on Friday.
- NLS receives deliveries from UPS, Fed Ex, SpeeDee Delivery, USPS, and other private courier services. Use any of these courier services to return sample to NLS.
- If you have any questions regarding this sampling kit, please call our Client Service Department at 800-278-1254

# Iron Bacteria - \$38

## Return your sample as soon as possible to:

Northern Lake Service  
2420 N Grandview Blvd  
Waukesha, WI 53188

## Please provide the following information:

Name: \_\_\_\_\_

Address: \_\_\_\_\_

City/State/Zip: \_\_\_\_\_

Phone: \_\_\_\_\_ Email: \_\_\_\_\_

Sample Collection Date: \_\_\_\_\_ Sample Collection Time: \_\_\_\_\_ AM/PM

Sample Collection Location (ex. Pressure Tank) \_\_\_\_\_

Sample Collected By: \_\_\_\_\_

Report by email only  Report by mail only  Report by email and mail