

Volatile Organic Compounds (VOC) Test Kit - \$126 List of 60+ compounds including: Vinyl Chloride, Benzene, Xylenes, Styrene, toluene, Trichloroethylene, Tetrachlorethylene, Methylene Chloride

Kit includes:

- 2 x 40 mL Clear Glass Vials with Hydrochloric Acid preservative
- 1 x 1 Ziplock bag TO BE FILLED WITH ICE PRIOR TO SHIPMENT

General Sampling Instructions:

Reminder: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH SAMPLE COLLECTION

*Sampling video available on our website at www.nlslab.com under support material

Do not dump/flush out any preservatives that may be present in your sampling containers. These are crucial for testing purposes. Always use caution when handling any sample container with preservatives and wash thoroughly with soap and water if preservatives would come into contact with skin.

- 1. Run water at maximum flow for at least 2 minutes.
- 2. Adjust the flow of the water to a slow continual stream (approximately a pencil width stream).
- 3. Hold vial at a slight angle and fill both 40 mL vials with your water until the water domes up just before overflowing.
- 4. Gently replace the cap. There should be no visible air bubbles in the vials when inverted. If air bubbles are present, gently add a bit more water and recap. **DO NOT DUMP OUT SAMPLE AND REFILL.**

Follow the return shipping instructions to ensure kit is shipped back to the lab properly:

- Fill out the required information below, and label your sample bottles with date/time of collection.
- Samples are accepted 7:00 am to 4:00 pm Monday Friday at the Crandon lab and 8:00 am to 4:00 pm Monday Friday at the Waukesha lab. If you are shipping your kit to NLS, samples MUST arrive at the laboratory no longer than 2 days from the time of collection. Do not ship on Friday.
- NLS receives deliveries from UPS, Fed Ex, SpeeDee Delivery, USPS, and other private courier services. Use any of these courier services to return sample to NLS.
- If you have any questions regarding this sampling kit, please call our Client Service Department at 800-278-1254

Volatile Organic Compounds (VOC) Test Kit - \$126

List of 60+ compounds including: Vinyl Chloride, Benzene, Xylenes, Styrene, toluene, Trichloroethylene, Tetrachlorethylene, Methylene Chloride

Return your sample as soon as possible to one of our two locations:

Northern Lake Service
400 N Lake Ave
Crandon, WI 54520

OR
Northern Lake Service
2420 N Grandview Blvd
Waukesha, WI 53188

Please provide the following information:

Name:	
Address:	
City/State/Zip:	
Phone:	
Sample Collection Date:	Sample Collection Time:AM/PM
Sample Collection Location (ex. Pressu	ure Tank)
Sample Collected By:	
Report by email only Report	rt by mail only Report by email and mail